

The Grip Clamp Mount

Separate the (2) elbows from the clamp assembly and then screw the (2) elbows into the side of the preamp module in the tapped holes on the jack side. When elbows are in place vertically positioned, screw the barrel nuts in place. **IMPORTANT: Place additional felt/padding/cork (included) where needed on the bottom of the preamp module and metal clamp lip to protect your instrument before mounting to your instrument**



